



EZ-Robot

Powering Up and Connecting your Robot

To ensure proper maintenance and care for your robot, be sure to follow these steps *every time* you power up you robot.

1. Load EZ Building software on your computer.
2. Turn your EZ-Robot on.
3. Lay your EZ-Robot on its back, if possible.
4. Connect your robot through your wifi settings
5. Connect your robot to the EZ Builder software.
6. Sync the robot to its servo profile.
7. Stand up your Robot (or have the robot stand on its own from the “stand from sit” function)